
VE12 Roll Grooving Tool



FOR STEEL, STAINLESS STEEL, ALUMINUM IPS, AND PVC PIPE

OGS

PARTS ORDERING INFORMATION


When ordering parts, the following information is necessary for Victaulic to process the order promptly:

- 1. Tool Model Number VE12
- 2. Tool Serial Number The Serial Number can be found on the side of the tool.
- 3. Quantity*, Item Number, Part Number, Description
- 4. Where to send the part(s) Company Name and Address
- 5. To whose attention to send the part(s)
- 6. Purchase Order Number

Parts may be ordered from your nearest Victaulic Sales Office.

 * Quantity given in $\ensuremath{\text{Qty.}}$ column indicates total number of pieces required per tool






| Item # | Part # | Qty. | Description | |
|--------|------------|------|---|--|
| 1 | R014012MCH | 1 | Gear Housing, Machining | |
| 2 | R0020120FS | 1 | Arm, Machining | |
| 3 | NS05080012 | 1 | Shoulder Screw, Hex Socket Head ½ x ¾ | |
| 4 | NS90010006 | 1 | Set Screw, Hex Socket Head Half Dog Point #10–24 x ¾ | |
| 5 | R0080260FS | 1 | Upper Shaft | |
| 6 | NM01000007 | 2 | Lubrication Fitting, ¼–28 Straight | |
| 7 | R900012UA2 | 1 | Upper Roll Assembly | |
| 8 | NB02100008 | 1 | Bearing, Needle Roller * | |
| 9 | NB05100002 | 1 | Thrust Washer | |
| 10 | R901012L02 | 1 | Lower Roll | |
| 11 | NB05225001 | 1 | Thrust Washer | |
| 12 | R902012A02 | 1 | Lower Roll Adapter | |
| 13 | NB02150006 | 1 | Bearing, Needle Roller | |
| 14 | NB05225002 | 1 | Thrust Washer | |
| 15 | NB03225001 | 1 | Bearing, Thrust Needle Roller | |
| 16 | NB05150002 | 1 | Thrust Washer | |

| Item # | Part # | Qty. | Description | |
|------------------------|------------|------|--|--|
| 17 | R017012MCH | 1 | Gear | |
| 19 | R015012MCH | 1 | Pinion | |
| 20 | NP80000010 | 1 | Pin, Slotted Spring 5/32 x 3/4 | |
| 21 | NB21050003 | 2 | Bearing, Flanged | |
| 22 | R0180260FS | 1 | Drive Nut | |
| 23 | NP01002104 | 1 | Pin, Slotted Spring 1/8 x 11/4 | |
| 24 | R012012MCH | 1 | Gear Cover Plate, Machining | |
| 25 | NP02004012 | 2 | Dowel Pin, ¼ x ¾ | |
| 26 | NS22010012 | 5 | Machine Screw, Hex Washer Slotted Head #10–24 x ¾ | |
| 28 | NB02150005 | 1 | Bearing, Needle Roller | |
| 29 | R0100260FS | 1 | Feed Screw | |
| 30 | NS05040104 | 1 | Shoulder Screw, Hex Socket Head ¼ x 1¼ | |
| 31 | NN15010000 | 2 | Locknut, Hex #10–24 | |
| * Included with Item 7 | | | | |





| Item # | Part # | Qty. | Description | |
|--------|------------|------|--|--|
| 32 | NM09000005 | 1 | Chain, No. 12 Single Jack | |
| 33 | R0200260FS | 2 | Narrow Depth Stop Collar | |
| 35 | R0130260FS | 1 | Front Plate | |
| 36 | NS03010008 | 2 | Cap Screw, Hex Socket Head #10–24 x ½ | |
| 37 | NP02003012 | 2 | Dowel Pin, ¾6 x ¾ | |
| 38 | NS05050112 | 1 | Shoulder Screw, Hex Socket Head 5/16 x 13/4 | |
| 39 | R0120260FS | 1 | Trunnion | |
| 40 | NS22010006 | 1 | Machine Screw, Hex Washer Slotted Head #10−24 x ¾ | |
| 41 | NT08000003 | 1 | Spring Clip | |
| 42 | NP01003112 | 2 | Pin, Slotted Spring ¾6 x 1¾ | |
| 43 | R0110260FS | 1 | Feed Nut | |
| 44 | R016012MCH | 1 | Pinion Shaft | |
| 45 | RLAB000010 | 1 | Warning Label † | |
| 46 | RLAB000009 | 1 | "C" Diameter Reference Label † | |

| Item # | Part # | Qty. | Description | |
|--------|------------|------|---|--|
| 47 | R027226LBL | 2 | Keep Hands Away Label † | |
| 48 | R3000260FS | 1 | Crank Assembly | |
| 48A | NM04000016 | 1 | Revolving Handle | |
| 48B | R3010260FS | 1 | Crank Arm | |
| 49 | NW01010000 | 1 | Washer, #10 | |
| 50 | R0800120FS | 1 | Gauge for ¾" Steel Pipe‡ | |
| 51 | R0810120FS | 1 | Gauge for 1", 1¼", 1½", and 2" Steel Pipe‡ | |
| 52 | R018012MCH | 1 | Serial Number Tag † | |
| 53 | NS09011010 | 2 | Cap Screw, Hex Socket Countersunk Head #10–32 x 5% | |
| 54 | NM04000001 | 1 | Handle | |
| 55 | NB05175004 | 1 | Thrust Washer | |

Refer to the following page for images of product labels
Included as part of the Gauge Assembly (Part Number R0820120FS)



IMAGES OF THE LABELS ON THIS PAGE ARE NOT TO SCALE.

RLAB000010

A WARNING Failure to follow instructions can result in serious personal injury, property damage, and Failure to follow instructions can result in serious personal injury, property damage, and product damage.
Before operating or servicing this tool, read and understand the operating and maintenance instructions manual and all labels located on this tool.
THIS IS A MANUALLY DRIVEN TOOL. DO NOT ATTEMPT TO OPERATE THIS TOOL WITH A POWER DRIVE.
A quarter turn of the depth stop collar will change the groove diameter 0.017 inch/0.4 mm.

- RLAB000010

3831 Rev. C

KEEP IANDS R027226LE

R027226LBL

RLAB000009

| SIZE | MAX. | 0. | D. | 5166 Rev. C ø"C" RLAB000009 | |
|------------------------------------|------|--------------|--------------|-----------------------------|--------------|
| SIZE | SCH. | MAXIMUM | MINIMUM | MAXIMUM | MINIMUM |
| ³ ⁄ ₄ [26.9] | 10 | 1.060 [26.9] | 1.040 [26.4] | 0.938 [23.8] | 0.923 [23.4] |
| 1 [33.7] | 40 | 1.328 [33.7] | 1.302 [33.1] | 1.190 [30.2] | 1.175 [29.9] |
| 1¼ [42.4] | 40 | 1.676 [42.6] | 1.644 [41.8] | 1.535 [39.0] | 1.520 [38.6] |
| 1½ [48.3] | 40 | 1.919 [48.7] | 1.881 [47.8] | 1.775 [45.1] | 1.760 [44.7] |
| 2 [60.3] | 40 | 2.399 [60.9] | 2.351 [59.7] | 2.250 [57.2] | 2.235 [56.8] |





Manufactured in Canada

R018012MCH

S/N

6276 Rev. A